



MESKER DOOR INC.

THE FIRST DOOR AND STILL THE FIRST DOOR

RECOMMENDATION ONLY FOR STAINING WOODGRAIN METAL

- #1 RULE.... NO DIRECT STAINING ONTO THE METAL SURFACE!
- A PRIMER SHOULD ALWAYS BE APPLIED FIRST.
 - THIS SHOULD BE A BASIC POLYESTER PRIMER (WHITE & BEIGE WORK WELL).
 - ONE ACCEPTIBLE PRIMER IS A POLYIMID #DTM-B66H50 CARRIED BY SHERWIN WILLIAMS STORES.
 - THIS PRIMER CAN BE SPRAYED ON OR APPLIED AS WITH A TRADITIONAL PAINT LINE.
- ONCE PRIMER HAS BEEN APPLIED AND DRIED, STAIN CAN THEN BE APPLIED.
 - THE STAIN CAN BE YOUR TYPICAL OLYMPIC BRAND STAIN OUT OF A CAN AND IS APPLIED IN THE SAME MANUAL WAY THAT SOMEONE WOULD STAIN WOOD.
 - ARTIST OIL (OIL BASED STAIN) IS ALSO USED BY SOME.
 - STAIN SHOULD BE APPLIED IN THE SAME DIRECTION OF THE WOODGRAIN.
- WHEN STAIN DRIES (MUST LET IT FULLY DRY), A CLEAR COAT PROTECTANT SHOULD BE APPLIED.
 - THIS ALSO SHOULD BE UV PROTECTANT.

HOPEFULLY THIS RECOMMENDATION HELPS ANSWER YOUR QUESTIONS. IF YOU HAVE ANY SPECIFIC QUESTIONS PLEASE REFER TO OLYMPIC WEBSITE: <http://www.ppg.com/ppgaf/olympic/staindoor2.htm>

NOTE: THESE ARE NOT OFFICIAL INSTRUCTIONS

JEFF BUCK
CUSTOMER SERVICE MANAGER